


Part 1


How to use FOXWELL NT604 Elite? (work out of box)




- 1.** Take out the scanner and main cable. Plug one end into your scanner and the other end into the OBDII port of your car. The scanner will turn on automatically.
- 2.** Turn on the ignition of your vehicle.
- 3.** According to your need, choose the targeted menu to start your diagnosis.
(If any support is needed, please don't hesitate to contact amazonsupport@foxwelltech.com)

For example:


If you want to diagnose 2016 nissan altima, then the right menu path should be:




①



③



②



④

Part 2

Warm Tips

- 1. About update:** FOXWELL NT604 Elite diagnostic tool can be used directly as it comes with existed software. You don't need to register or update before the first use.
- 2. About language:** If you want to activate other languages such as French, please kindly send us the serial number of your machine. We will activate it for free.
- 3. About compatibility:** The compatibility will differ from specific year, vehicle and VIN. If it fails to work on your vehicle , please feel free to contact us for fast tech support. Our engineer will help you solve the problem.
(amazonsupport@foxwelltech.com)
- 4. About return:** if you choose to return this scanner, please kindly mark it unsellable to avoid a used one is resold again to other customers. Really appreciate your understanding.

Part 3

Register and update


🕒: When should I update my scanner?

A: Generally, the scanner could be used directly. It's recommended to update your scanner only when the following situations occur: it fails to work on your car, it's slow to load all menus or if you need newer software version.


How to start registration and update?

(only computer with windows 7, 8 and 10 are supported. **Mac or ios is not supported.**)


1. Visit website: www.foxwelltech.us
Select "tools" under column support.



2. Scroll down the page and download update tool for your scanner. Install the update tool on your computer and open it.



3. Click register and input your email address to receive code and set your password.



4. Remove off the SD card from your scanner (The SD card is at the bottom of the scanner). Insert the SD card into your card reader and then insert them into your computer.
(card reader is in the package.)




5. Open the update tool and sign in with the email address and password.



6. Your SN will be auto detected. Click "Activate".



7. Click "download" and "update".



8. Please remove off the SD card from your card reader and insert it into your scanner.



Part 4

FAQs

1. Q: If it can not work on my vehicle, how can I get tech support?

A: Please reach us at the first time. Our engineer will offer tech support to solve your problem. Fast response will be given within 24 hours. We'll definitely offer you a satisfactory solution.
(amazonsupport@foxwelltech.com)

2. Q: What should I do if there are some scratches on the screen?

A: There is a tightly-fitting screen protector on your machine. If any scratches are found, just tear off the screen protector from the upper left or upper right corner.

3. Q: If I receive used or defective machine, what shall I do?

A: All our products are sent to FBA center as brand new through the strict security check by Amazon. But around 1% customer return goods will be marked as sellable by Amazon without our control. If you receive defective or used one, please contact us for replacement.

4. Q: Will it do some service reset like oil light reset or abs bleeding?

A: Please kindly note that FOXWELL NT604 Elite doesn't support maintenance reset function. NT604 Elite is a diagnostic scanner for abs, srs, transmission and check engine system.

Part 5

Contact us

🌐: www.foxwelltech.us

✉: amazonsupport@foxwelltech.com

